

ULTIMATEMETAL BY CHROMALUXE

CARE GUIDE

ChromaLuxe coated aluminum is designed for easy routine care. Gentle cleaning and careful handling will help preserve the surface, edges, and mounting system.

THREE-STEP ROUTINE

1 Remove Loose Dust

Use a clean, dry microfiber or lint-free cloth. Wipe lightly so particles are not dragged across the face.

2 Clean Smudges

Use a slightly damp cloth. If needed, add a small amount of household all-purpose or glass cleaner to the cloth.

3 Dry the Surface

Finish with a second clean cloth. Check that no moisture remains near edges, seams, hardware, or the frame.

RECOMMENDED

- Use soft, clean microfiber or lint-free cloths.
- Support larger panels with two hands when moving them.
- Lift panels instead of sliding or dragging them.
- Ask Image Craft before establishing a repeated disinfecting protocol.

AVOID

- Abrasive pads, scouring powders, or coarse paper products.
- Sharp tools, scraping, or forceful rubbing on the printed face.
- Acetone, paint thinner, or unapproved specialty chemicals.
- Excess liquid around edges, backing, mounting hardware, or frames.

DISPLAY AND PRODUCT SELECTION

● Protect the face and edges during storage or transport.

Do not stack panels face-to-face without clean protective interleaving. Keep artwork where edges cannot be struck or bent.

● Confirm the correct product for outdoor display.

Standard ChromaLuxe Indoor panels are not for permanent outdoor or direct-sun installations. Ask Image Craft about ChromaLuxe Outdoor options.

Questions about cleaning, damage, mounting, or outdoor exposure?

Contact Image Craft at (602) 276-2082 or Sales@imcraft.com.